

LED Solar Rechargeable Torch – Solar & Electric-Charged

Instruction Manual



Dimension: 118.6 x 67.7 cm

Rating: 220-240V~,50Hz, 3W

IP: IP33



Model: 543312

Serial number located of the back of the unit.

Please keep this instruction manual.

Please read the manual before using the torch.

IMPORTANT SAFEGUARDS

- 1. Please read all instructions before using this product. And keep this safety instructions for your future reference.
- 2. Keep away from children and disable persons when using the product. Children must be supervised by adults before and during use.
- 3. Children should be supervised to ensure that they do not play with the appliance.
- 4. Children, elderly people with limited mobility, people with physical, sensory or mental impairments and lack of experience and knowledge should be using the product under the care or guidance by person responsible for their safety.
- 5. Do not use it while it is recharging so as to avoid damaging the internal components.
- 6. Do not point the light to eyes directly, or it will affect eye sight.
- 7. Keep it away from rain and dampness.
- 8. Keep it away from explosives and flammables while it is charging. The charging time cannot exceed 12 hours. Charging recommended during day time.
- 9. Do not drop. Do not open the appliance for repair or cleaning.
- 10. Replace the charging cable if it is damaged. Product should be replaced or repaired by a qualified professional.
- 11. Never put the product into water in the bath or other water containers.

WARNING

In order to avoid a hazard, please keep electrical appliances out of reach from children or infirm persons. Do not let such persons use the appliance without supervision. Do not connect the cable into a socket-outlet which is exposed to splashing water. The torch shall not be connected to covered socket outlets. Plug the provided cable directly into an appropriate power charging sources. To provide continued protection against risk of electric shock, connect to properly grounded outlets only. Do not immerse in water.

SPECIFICATION

Power Source: 220-240 VAC, 50Hz

Rating Power Input: 3 WTorch Luminous: 330 Lm

Weight: 0.3 kgSolar charging


- Rechargeable, durable, long battery life, portable, lightweight, non-slip grip.
- Run time 7 hours, Charging time up to 6 hours
- Battery 800mAh

OPERATING INSTRUCTIONS

Please read the installation instruction carefully to understand how the torch works.

- 1. During charging, connect the charging cable to the 5V charging port of the charger and the torch. The product indicator light will turn on with a red colour indicating that it is in charging status. It takes up to 6 hours to fully charge. When using solar charging, align the solar panel with direct sunlight to charge the built-in battery. The red power indicator light will turn on, indicating that it is in charging status. Charging under strong light can take about 10 hours to fully charge.
- 2. Soft light or strong light mode can be chosen by pushing the switch button.
- 3. After fully charged, the light can last working for about 7 hours in soft light and about 4 hours in strong light mode.
- 4. When the light becomes dim during use, that means the battery is in low power. At this moment, stop using it and recharge it in time so as to protect the battery. Recharge it before the light stops working otherwise it will cause damage to the battery.
- 5. Frequent use is required, long-time none use is not recommended. If you don't use it very often, recharge it every 3 months, or the battery's lifespan will be shortened.







3W Torch

Built-in Solar Panel

Soft / Strong Light

MAINTENANCE

If the charging cable is damaged, it must be replaced by a qualified professional to avoid danger.

CLEANING

- 1. Do not put the product, charging cable and/or plug into the water.
- 2. Never clean the product with alcohol or solvent-based cleansers.
- 3. Please clean the surface by wet towel first and then dry it with a soft cotton cloth.

NOTE: Do not use a metal ball or a rough cloth to wipe the torch, it will scratch the surface of the product.

4. Please do not us alcohol or solvents on plastic components, it will cause the cracking and ageing of these parts.

Correct Disposal of this product



This marking indicates that this product should not be disposed with other household wastes throughout the UK or the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources, or dispose your used device at your local recycling center.

WARRANTY INFORMATION

The manufacturer provides warranty in accordance with the legislation of the customer's country of residence, with a minimum of 1 year warranty, starting from the date on which the appliance is sold to the customer. The warranty only covers defects in material or workmanship. When making a claim under the warranty, the original bill of purchase (with purchase date) must be submitted.

The warranty will not apply in cases of:

- Normal wear and tear.
- Incorrect use, e.g. battery failure from lack of regular charge, use of non-approved maintenance.
- Use of force, damage caused by external influences.
- Damage caused by non-observance of the user manual, e.g. connection to an unsuitable charge source or non-compliance with the instructions.
- Partially or completely dismantled appliances.

REGISTER WARRANTY: Register your product online at www.bgepro.com/warranty within 14 days of purchase to validate your warranty. Note the model and serial number (if applicable) for your product before registering. Proof of purchase is necessary for a warranty claim.

For more information contact us at info@bgepro.com. Some products and promotions may be excluded from this offer.

Terms & Condition of Purchase

BridgePro Management Ltd ("BPM").

Limited Warranty: This product is guaranteed for 12 months from the date of original purchase. This guarantee is valid in the UK only. If any defect arises due to faulty materials or workmanship, the faulty products must be returned to the place of purchase. Refund or replacement is at the discretion of the retailer.

The following conditions apply:

- The product must be returned to the retailer with proof of purchase or a receipt.
- The product must be installed and used in accordance with the instructions contained in this instruction guide.
- It must be used only for domestic purposes.
- It does not cover wear and tear, damage, misuse or consumable parts.
- The product has limited liability for incidental or consequential loss or damage.

To validate your warranty, please visit www.bgepro.com/support/warranty/ and register with us online. Warranty is only valid with proof of purchase or receipt.

This product warranty is available to consumers only.

You are a consumer if you purchased the product at retail for personal, family, or household use. Except as otherwise stated under applicable law, this warranty is not available to retailers or other commercial purchasers and owners.

This product warranty is void if the product is used for situations other than a single-family household use or subjected to any voltage and wave forms other than as specified in this instruction manual (e.g., 220V-50Hz).

Transportation charges: Transportation charges for products under this warranty, subject to repair or replacement, shall be borne by the purchaser.

Conditions: Service centers or retail stores do not have the right to alter, modify, or in any way change the terms and conditions of this warranty.

Warranty registration is not necessary but is encouraged to validate product warranty.

About your warranty: Most warranty repairs or replacements are handled routinely but sometimes requests for warranty services may not be appropriate, e.g., warranty services would NOT apply if the product damage occurred because of misuse, lack of routine maintenance, shipping, handling, 3rd party warehousing, or improper installation. Similarly, warranty is void if the serial number on the product has been removed or the product has been altered or modified.

Normal wear: This warranty does not cover normal wear of any parts or damage resulting from any of the following negligent use or misuse of the product:

- Improper voltage or current,
- Use contrary to the operation instructions,
- Deviation from the instructions regarding storage and transportation, or
- Repair or alteration by any 3rd party.

This warranty does not cover Acts of God such as fire, flood, hurricanes, and tornados.

BPM shall not be liable for any incidental or consequential damages by the breach of any express or implied warranty. Except to the extent prohibited by applicable law any implied warranty of merchantability or fitness for the particular purpose is limited in duration of this warranty.

Notes